

V&V Summary Report

L2 ASCDS Version : 10.8

Observation 21403 - L2 Version 2
Chandra X-Ray Center

L2 Processing Date : Sep 26 2019

See [axaff21403N002_VV001_vvref2.pdf](#) for the full report

V&V Scientist	Beth Sundheim
V&V Date (YYYY-MM-DD)	2019.09.27
V&V Edition	1
V&V Disposition and Status	OK
V&V Charge Time	18.077277457356

Comments

ACIS T_GAIN files released in CalDB 4.8.3 (23 May 2019) and CalDB 4.8.4 (03 September 2019) have errors in the T_GAIN corrections for ACIS-I chips 0, 1, 2, and 3, and ACIS-S chip 6 (S2). All ACIS OBS_IDs including those chips, which were processed (or reprocessed) in SDP between 2019-05-24T01:06:00 and 2019-09-06T17:31:43 with CalDB 4.8.3, 4.8.3.1, or 4.8.4, were affected. The errors in the T_GAINs, which produce a 1%-2% reduction in the PHA and hence the ENERGY column values for dithered observations, result from alternating real value and zero value columns in CHIPX space across FI chips ACIS-0, 1, 2, 3, and 6. The error has been corrected in this version of the data products.

==

The focal plane temperature during part of this observation was warmer than the upper limit for optimum calibration of the ACIS gain and spectral resolution (i.e., -111.0 C for ACIS-S). The Chandra calibration team calibrates the ACIS gain and spectral resolution using data from the external calibration source (ECS). ECS data show that the frontside-illuminated (FI) CCDs are more temperature-sensitive than the backside-illuminated (BI) CCDs. A summary of the current calibration status of the ACIS gain and spectral resolution can be found at:

http://asc.harvard.edu/cal/Acis/Cal_prods/Gain_and_Spectral_Resolution/A

The main points are:

- 1) The gain on BI chips remains within 0.3% (i.e., the systematic uncertainty in the ACIS gain quoted on the Chandra Calibration Status Summary web page) at all measured temperatures.
 - 2) The gain on FI chips remains within 0.3% below row 600 at all measured temperatures.
 - 3) The gain on FI chips above row 600 can be underestimated by as much as 1% for focal plane temperatures exceeding -116 C.
 - 4) The spectral resolution (i.e., FWHM) on BI chips is insensitive to the focal plane temperature.
 - 5) Warmer focal plane temperatures increase the FWHM on FI chips by up to 30 eV near row 512 and by up to 70 eV near the top of the chips.
- In summary, the user should be cautious in the spectral analysis of high S/N emission lines detected on the top half of FI chips in this observation. Default processing with the current version of the CALDB will underestimate photon energies by up to 1% and broaden emission lines by up to 70 eV.

seq_num	703701	Sequence number
obs_id	21403	Observation id
title	COMPLETING THE CHANDRA EXTRAGALACTIC 3CR SURVEY	Proposal title
observer	Francesco Massaro	Principal investigator
object	3CR 454.0	Source name
dtcycle	0	
cycle	P	events from which exps? Prim/Second/Both
ra_targ	342.894583	Observer's specified target RA [deg]
dec_targ	18.811139	Observer's specified target Dec [deg]
ra_nom	342.89411794743	Nominal RA [deg]
dec_nom	18.808618864104	Nominal Dec [deg]
roll_nom	161.15680298658	Nominal Roll [deg]
revision	2	Processing version of data
ontime	18077.277457356	Sum of GTIs [s]
liveltime	17833.317671609	Livetime [s]
ontime6	18074.195327044	Sum of GTIs [s]
ontime7	18077.277457356	Sum of GTIs [s]
l2events	89700	Number of level 2 events

